

## Tools Required for Remodeling

### Remodeling-Equipment/Tools

**Flat and Phillips Screwdrivers**-Two different screwdrivers are needed for the job because there are different screws that are used for different types of jobs. The screwdriver is used in most every job in the remodeling field. It is used when changing electrical outlets, replacing garbage disposals, putting on outlet covers, and installing new lights and door handles.



**Drill**- Similar to the screwdriver, the drill is used to screw in different types of screws but in a faster rate. The drill is also used for cutting in door handles by putting on a different tip. You can cut circles in the door to create a spot for new door knobs. You can also use the drill to remove screws. For example, you can take a screw out of a cabinet easier than using just a regular screwdriver. The drill is often used for hanging doors and cabinets, and installing outlet covers. When building things, you can drill a nail to hold the wood pieces together. For example, you can do this when creating decks and balconies.



**Hammer-** The hammer is used for nailing, removing nails, or breaking things. The hammer is often used when removing drywall to break down the walls or tear up tile in bathrooms.



**Level-** This tool is used to make sure that anything that you are hanging is balanced or not crooked. For example, when hanging kitchen cabinets, you would use a level to make sure that they are hung straight. If they aren't hung straight, then the doors won't close correctly.



**Saw-** The saw is used to cut wood or other type of materials for the job. For example, when cutting wood for baseboards you would use the saw.



**Nailgun-** The nail gun shoots nails into wood or other materials. For example, the nail gun can be used to put siding on decks.



**Receptacle-** When you change an outlet you would use this tool to make sure it is working properly.



**Paint Brush and Painting Supplies-** The paint brush is used to paint the walls and doors for the job. It can also be used to cover scratches on the walls or doors.

